


Project Listings

Project #	Description	Page #	Project #	Description I	Page #	Project #	Description Pa	age #
1	Color Light	18	32	Automatic Light	31	63	Resistors & LEDs	42
2	White Light	18	33	Color Oscillator	31	64	Low Power Brightness Control	43
3	Red Light	18	34	Dance to the Music	32	65	Low Power Resistors & LEDs	43
4	Light Show	19	35	Super Dance to the Music	32	66	Persistence of Vision	43
5	Voice Light Show	20	36	Super Dance to the Music (II)	32	67	Prismatic Film	44
6	Play the Color Organ	20	37	Follow the Music	33	68	Look at the Lights	44
7	Flying Saucer	21	38	Color Organ - Headphones	33	69	Scattering Light	44
8	Super Flying Saucer	21	39	Adjustable Light Dance	34	70	Color Fiber Light	44
9	Big Circuit	22	40	Suspended Raindrops	34	71	One Way Plastic	45
10	Box Cover Circuit	23	41	Infrared Detector	35	72	White Blinker	45
11	Blinking Colors	24	42	Audio Infrared Detector	35	73	Red Blinker	45
12	Fiber Optics	24	43	Photo Infrared Detector	36	74	Red & White	45
13	Tones Over Light	25	44	Photo Audio Infrared Detector	36	75	Color Selector - Red	46
14	Color Optic Sounds	25	45	Photo Audio Infrared Detector (II) 36	76	Color Selector - Green	46
15	Color Light Transporter	26	46	Strobe Effects	37	77	Color Selector - Blue	46
16	Color Optics	26	47	Slow Strobe Effects	37	78	Color Selector - Cyan	46
17	High Power Fiber Optics	27	48	Stable Strobe Effects	38	79	Color Selector - Yellow	46
18	High Color Optics Sounds	27	49	Strobe Effects (II)	38	80	Color Selector - Purple	46
19	Sound Maker	28	50	Strobe Effects (III)	38	81	Color Selector - White	46
20	Strobe Light	28	51	Strobe Effects (IV)	38	82	LED Color Spectrum	47
21	Color Strobe Light	28	52	Strobe Effects (V)	38	83	LED Color Spectrum (II)	47
22	Red Strobe Light	28	53	Strobe Effects (VI)	39	84	LED Color Spectrum (III)	47
23	Noisy Strobe Light	29	54	Make Your Own Strobe Effects	s 39	85	LED Color Spectrum (IV)	47
24	Noisy Red Strobe Light	29	55	Another Strobe Light	39	86	LED Color Spectrum (V)	47
25	Double Strobe Light	29	56	Motor Strobe Effects	40	87	Blinking Beeping	48
26	Louder Strobe Light	29	57	Motor Strobe Effects (II)	40	88	Blinking Blinking	48
27	Louder Color Strobe Light	29	58	Motor Strobe Effects (III)	40	89	Blinking Control	48
28	Triple Strobe Light	30	59	LEDs Together	41	90	Blinking Control Beeping	48
29	Noisy Double Strobe Light	30	60	LEDs Together (II)	41	91	Triple Blinker	49
30	Noisy Triple Strober	30	61	Brightness Control	42	92	Funny Speed Motor	49
31	Triple Light Noisy Motion St	rober 30	62	Resistors	42	93	Funny Speed Motor with Light	49

Project Listings

Project #	Description	Page #	Project #	Description I	Page #	Project #	Description	Page #
94	Light Dance Audio Override	50	125	Wacky Buzzer	58	156	Photo Current Amplifier	71
95	Light Dance Light Override	50	126	Fiber Fun	59	157	LEDs & Transistors	71
96	Counting Light	51	127	Fiber Fun Backwards	59	158	PNP Amplifier	71
97	Adjustable Counting Light	51	128	More Fiber Fun	59	159	Photo Control	72
98	Bright Off Light	52	129	Other Fiber Fun	59	160	Resistance Director	72
99	R/C Blink & Beep	52	130	Morse Code	60	161	Current Controllers - Series	73
100	Stuck On Light	53	131	Fiber Shut-Off	60	162	Current Controllers - Parallel	73
101	Stuck On Lights	53	132	Blow On Fiber	61	163	Blow Sound Changer	74
102	White Blinker	53	133	Fiber Music	61	164	Short Light	74
103	Low Voltage Stuck On Lights	53	134	Fiber Color Organ	62	165	Shorter Light	74
104	Stuck On Motor & Lights	53	135	Bright Fiber Color Organ	62	166	Photo Light Control	75
105	Funky Light & Sound	54	136	Motor Power	63	167	Air Pressure Light Control	75
106	Light & Sound	54	137	More Motor Power	63	168	Slow On, Slower Off	75
107	Light & Motion	54	138	Reflection Detector	63	169	Delayed Photo Speed Contro	ol 76
108	Adjustable Light & Sound	54	139	Cup & String Communication	64	170	Delayed Speed Control	76
109	Adjustable Light & Motion	54	140	Slow Motor Speed Control	65	171	Delayed Speed Control (II)	76
110	Blinking Step Motor	55	141	Slow Motor Start Aid	65	172	Audio Delayed Speed Contro	ol 76
111	Blink Step Beep	55	142	R/C Motor	65	173	Photo Speed Control	76
112	Day Blinker	56	143	Series Lights	66	174	Light Buzz	77
113	Night Blinker	56	144	Wacky Sound Control	66	175	Delay Lights	77
114	Night Light Show	56	145	Musical Shapes	67	176	Touch Light	78
115	Daylight Light Show	56	146	Human & Liquid Sounds	67	177	Narrow Range Tone	78
116	Buzzer	57	147	Human & Liquid Light	67	178	Slow Off Lights	78
117	Higher Pitch Buzzer	57	148	Blow On the Light	68	179	3D Pictures	79, 80
118	Photo Light & Motion	57	149	Blow Off the Light	68	180	Super Infrared Detector	80
119	Slow Light & Motion	57	150	Transistor	69	181	Infrared Optical Audio	81
120	Light Up the Fan	57	151	Another Transistor	69	182	Test the Color Organ	81
121	High Power Buzzer	58	152	Charging & Discharging	70			
122	Buzz Fan	58	153	Mini Capacitor	70			
123	Photo Buzzer	58	154	Adjustable Charging & Discharging	ng 70			
124	Step Beeper	58	155	Mini Battery	70			

Color Light





Snappy says the color LED actually contains separate red, green, and blue lights, with a microcircuit controlling them.

0

Snap Circuits® uses electronic blocks that snap onto a clear plastic grid to build different circuits. These blocks have different colors and numbers on them so that you can easily identify them.

Build the circuit shown on the left by placing all the parts with a black 1 next to them on the board first. Then, assemble parts marked with a 2. Install two (2) "AA" batteries (not included) into each of the battery holders (B1) if you have not done so already.


Turn on the slide switch (S1), and enjoy the light show from the color LED (D8). For best effects, place one of the LED attachments (tower, egg, or fiber optic tree) on the color LED, and dim the room lights. The fiber optic tree must be used with its mounting base.

White Light **Project 2**

The white LED produces very bright light. LEDs are this one are increasingly being used for home lighting and flashlights. They are more efficient than normal light bulbs.

Use the circuit built in project 1, but replace the color LED (D8) with the white LED (D6). Try it with one of the LED attachments, and in a dark room.





Project 3

Red Light

0


The red LED is not nearly as bright as the other LEDs. LEDs like this one are used as indicators in many products in your home. They are inexpensive, but don't produce much light.

Use the circuit built in project 2, but replace the white LED (D6) with the red LED (D1). Try it with one of the LED attachments, and in a dark room.



-18-

Light Show



Snap Circuits[®] uses electronic blocks that snap onto a clear plastic grid to build different circuits. These blocks have different colors and numbers on them so that you can easily identify them.

Build the circuit shown above by placing all the parts with a black 1 next to them on the board first. Then, assemble parts marked with a 2. Then, assemble parts marked with a 3. Then, assemble parts marked with a 4 (just one end of the red jumper wire, in this circuit). Install two (2) "AA" batteries (not included) into each of the battery holders (B1) if you have not done so already.

If desired, place any of the LED attachments (tower, egg, or fiber optic tree) on any of the LEDs (red (D1), color (D8), white (D6), or the LED on the color organ IC (U22). Note that the fiber optic tree requires its mounting base.

Turn on slide switch (S1) and enjoy the show!

All the lights in this set are LEDs - Light Emitting Diodes. LEDs convert electrical energy into light; the color of the light emitted depends on the characteristics of the material used in them.



012

0

0

0

0

0

0

01

SLIDE

0 3 0

BO

J22)

COLOR

DO

E(O

0

0

0

0




Build the circuit as shown, and place one of the LED attachments (tower, egg, or fiber optic tree) over the LED on the color organ (U22). Turn on the switch (S1) and talk. The color organ light will follow your voice, in tone and loudness.

How does it work? The microphone converts your voice to an electrical signal, which controls an electronic counter in the color organ. The counter controls a red-green-blue LED.

Project 6

SWITCH



Play the Color Organ

Build the circuit as shown, and turn on the switch (S1). Place one of the LED attachments on the color organ (U22). Wet your fingers, and touch them between the point marked "X", and points marked "R", "G", or "B" in the drawing. Try X with every combination of R, G, and B, including touching them all at the same time.

The light in the color organ module is actually red, gree, and blue LEDs together. The points marked R, G, and B control the light for those colors. Combining red and green makes yellow, green and blue makes cyan, red and blue makes purple, and combining all three colors makes white.

LED Attachments

Test Equipment Depot - 800.517.8431 - 99 Washington Street Melrose, MA 02176 TestEquipmentDepot.com


LED

Attachments

0

0

Flying Saucer



The air is being blown down through the blade and the motor rotation locks the fan on the shaft. When the motor is turned off, the blade unlocks from the shaft and is free to act as a propeller and fly through the air. If speed of rotation is too slow, the fan will remain on the motor shaft because it does not have enough lift to propel it.



Push the press switch (S2) until the motor reaches full speed, then release it. The fan blade should rise and float through the air like a flying saucer. Be careful not to look directly down on fan blade when it is spinning.

If the fan doesn't fly off, then press the switch several times rapidly when it is at full speed. The motor spins faster when the batteries are new.

The glow fan will glow in the dark. It will glow best after absorbing sunlight for a while. The glow fan is made of plastic, so be careful not to let it get hot enough to melt. The glow looks best in a dimly lit room.

WARNING: Moving parts. Do not touch the fan or motor during operation. Do not lean over the motor. Fan may not rise until switch is released.

Project 8

Super Flying Saucer


This circuit will make the fan spin faster and fly higher than the preceding circuit, making it easy to lose your fan.

WARNING: Elenco[®] Electronics Inc. is not responsible for lost or broken fans! You may purchase replacement fans at www. snapcircuits.net.


Push the press switch (S2) until the motor reaches full speed, then release it. The fan blade should rise and float through the air like a flying saucer. Be careful not to look directly down on fan blade when it is spinning.



WARNING: Moving parts. Do not touch the fan or motor during operation. Do not lean over the motor. Fan may not rise until switch is released. Eye protection is recommended for this circuit.



Big Circuit




Build the circuit as shown. Place either the glow fan or the light fan on the motor (M1) shaft, so that it is stable on the little black piece. Place the clear fiber optic holder on the color LED (D8) and the black fiber optic holder on the phototransistor (Q4), then insert the fiber optic cable between them, but don't let it lay close to the fan on the motor. For best performance the fiber optic cable should stand straight up in the holders, without bending them. Connect a music device to the color organ (U22) as shown, and start music on it. For best effects, place one of the LED attachments over the light on the color organ.

Turn on slide switch (S1). Adjust the lever on the adjustable resistor (RV) and the volume control on your music device for best sound and light effects.

Push the press switch (S2) until the motor reaches full speed, then release it. The fan will rise into the air like a flying saucer. Be careful not to look down on the fan when it is spinning. If desired, connect the light fan blade to the charger for a while to charge it, then place it on the motor to spin or launch it.

"Playing the Color Organ": turn off or disconnect your music device. Wet your fingers, and touch them between the point marked "X", and "R", "G", or "B" in the drawing.

The infrared detector (U24) and $100k\Omega$ resistor (R5) are only used to support the other components.



Box Cover Circuit

This circuit is called the Box Cover Circuit because it is pictured on the front of the Snap Circuits[®] LIGHT box, use that picture to help in building it.



Build the circuit as shown. Place the glow fan on the motor (M1) shaft, so that it is stable on the little black piece. Place the clear fiber optic holder on the white LED (D6) and the black fiber optic holder on the phototransistor (Q4), then insert the fiber optic cable between them, but don't let it lay close to the fan on the motor. For best performance the fiber optic cable should stand straight up in the holders, without bending them. For best effects, place one of the LED attachments over the light on the color organ, and one on the color LED (D8).


Optional: connect a music device to the color organ (U22) as shown, and start music on it (the color organ light will change to the music, but you will not hear it unless you also connect headphones).

Turn on slide switch (S1). A tone is hear from the speaker (SP), and all the lights (D1, D6, D8, and on U22) are on.


Push the press switch (S2) until the motor reaches full speed, then release it. The fan will rise into the air like a flying saucer. Be careful not to look down on the fan when it is spinning.

WARNING: Moving parts. Do not touch the fan or motor during operation. Do not lean over the motor. Fan may not rise until switch is released.

Blinking Colors



Red light is easier for LEDs to produce than white light. When the red and white LEDs are connected in parallel (which happens when S2 is pressed), the red LED will dominate because it turns on more easily.




Build the circuit as shown and turn on the slide switch (S1). The white and color LEDs (D6 & D8) are blinking.

Push the press switch (S2). Now the red LED (D1) is blinking but the white LED is off.

If you swap the locations of the red and white LEDs, then the red LED will be blinking and the white LED will be off, and pushing the press switch won't change anything.

Project 12



Fiber Optics

Build the circuit as shown. Place the clear cable holder on the red LED (D1) and the black cable holder on the phototransistor (Q4), then place the fiber optic cable into the holders as far as it will go. For best performance the cable should stand straight up in the holders, without bending them.

Turn on slide switch (S1) and move the lever on the adjustable resistor (RV) around. The sound from the speaker (SP) changes as you move the lever on RV.


This project is more exciting than it looks. The tone sounds produced by the strobe IC (U23) are played on the speaker (SP), even though there is no electrical connection between them.

The left half the circuit makes a coded light signal, which you see in the red LED (D1). The right half of the circuit decodes the light signal and plays it on the speaker. The fiber optic cable is used to transmit the light signal between the two sides of the circuit. There is no electrical connection between the left and right halves of the circuit, only a light connection using fiber optics! If your fiber optic cable was longer, the two halves of the circuit could be many miles apart.

This circuit is an example of using fiber optic cables for communication. Fiber optics allows information to be transmitted across great distances at very high speeds with very low distortion, by using light.



Tones Over Light



Build the circuit as shown. Place the clear cable holder on the red LED (D1) and the black cable holder on the phototransistor (Q4), then place the fiber optic cable into the holders as far as it will go. For best performance the fiber optic cable should stand straight up in the holders, without bending them.

Turn on the slide switch (S1) and move the lever on the adjustable resistor (RV) around. The sound from the speaker (SP) changes as you move the lever on RV.

This is similar to project 12 but not as loud. The project 12 circuit uses a two-transistor amplifier while this circuit only has one transistor.


0

Project 14


Color Optic Sounds

Build the circuit as shown. Place the clear cable holder on the color LED (D8) and the black cable holder on the phototransistor (Q4), then place the fiber optic cable into the holders as far as it will go. For best performance the fiber optic cable should stand straight up in the holders, without bending them.

Turn on the slide switch (S1) and push the press switch (S2). Light is transmitted from the color LED, through the fiber optic cable, to control the strobe IC (U23) and speaker (SP).



Color Light Transporter





Build the circuit as shown. Place the black cable holder on the color LED (D8), then place the fiber optic cable into the holder as far as it will go. For best performance the fiber optic cable should stand straight up in the holder, without bending it. Leave the other end of the cable free.

Turn on the switch (S1), and look into the loose end of the fiber optic cable. Flex the cable into loops but don't dent it. Take the circuit into a dark room and see how the cable looks.


You can use the clear cable holder on the color LED instead of the black holder.


Project 16

Color Optics

Build the circuit as shown. Place the clear cable holder on the color LED (D8) and the black cable holder on the phototransistor (Q4), then place the fiber optic cable into the holders as far as it will go. For best performance the fiber optic cable should stand straight up in the holders, without bending them.

Turn on the switch (S1). The color LED (D8) turns on and off repeatedly as it changes colors. This produces interesting effects when connected to the speaker circuit through the fiber optic cable.





High Power Fiber Optics

Build the circuit as shown. Place the clear cable holder on the white LED (D6) and the black cable holder on the phototransistor (Q4), then place the fiber optic cable into the holders as far as it will go. For best performance the fiber optic cable should stand straight up in the holders, without bending them.

Turn on the slide switch (S1) and move the lever on the adjustable resistor (RV) around. The sound from the speaker (SP) changes as you move the lever on RV.

Try removing the black cable holder and just holding the fiber optic cable next to the phototransistor with your fingers. Hold it at different angles and compare the sound. You may not hear anything, due to background light in the room. Take the circuit into a dark room or place your fingers around the phototransistor to block the room light to it. Now put the black cable holder back on, remove the clear cable holder, and try holding the fiber optic cable at different positions around the white LED. You can also replace the white LED with the red LED (D1) or the color LED (D8).

Project 18 6 0 0 0 0 Black 0 SP U23 0 Strobe IC 012 0 0 Clear

High Color Optics Sounds


Build the circuit as shown. Place the clear cable holder on the color LED (D8) and the black cable holder on the phototransistor (Q4), then place the fiber optic cable into the holders as far as it will go. For best performance the fiber optic cable should stand straight up in the holders, without bending them.

Turn on the slide switch (S1). Light is transmitted from the color LED, through the fiber optic cable, to control the strobe IC (U23) and speaker (SP).


The circuits on this page are similar to projects 12 and 14, but have the fiber optic transmitting sub-circuit (with the LED) and the receiving sub-circuit (with the phototransistor) using the same voltage sources. Normally the transmitting and receiving circuits will be in different locations with separate voltage sources, but they were combined here to increase the power.



Sound Maker



The strobe IC (U23) produces an electrical "tone". The pitch of the "tone" is adjusted by changing how much electricity flows into its upper-left snap, using a resistor. The electrical tone it produces can be used to make sound using a speaker, or to control the flash rate of an LED see project 20, the Strobe Light).



Build the circuit and turn on the switch (S1). You hear sound from the speaker. Adjust the sound using the lever on the adjustable resistor (RV), and by pushing the press switch (S2).

Note: In rare cases the circuit may not work at all settings on RV. If this happens, move the RV lever to the side near the strobe IC, turn the slide switch off and on to reset the circuit, and only move the RV lever over a small range.

Project 20 Strobe Light

Use the preceding circuit, but replace the speaker with the white LED (D6). Now you have a strobe light!

When S2 is pressed, the light may be blinking so fast that it appears to be on continuously.

Project 21 Color Strobe Light

Use the preceding circuit, but replace the white LED with the color LED (D8).


The color LED will not be changing colors like it does in other circuits. When the strobe IC (U23) turns the color LED on and off, it resets the colorcontrol microcircuit in the color LED. Even your slowest strobe speed is too fast for the color LED.



Project 22 Red Strobe Light

Use the preceding circuit but replace the color LED (D8) with the red LED (D1).

Project 23 Noisy Strobe Light



Modify the project 19 circuit to be this one, which has the white LED (D6) next to the speaker (SP). Build the circuit and turn on the switch (S1). Adjust the blink rate and sound using the lever on the adjustable resistor (RV), and by pushing the press switch (S2).

Note: In rare cases the circuit may not work at all settings on RV. If this happens, move the RV lever to the side near the strobe IC, turn the slide switch off and on to reset the circuit, and only move the RV lever over a small range.


Project 24 Noisy Red Strobe Light

Use the preceding circuit but replace the white LED (D6) with the red LED (D1) or the color LED (D8).

Project 25 Double Strobe Light

Use the preceding circuit but replace the speaker and LED with any two LEDs (red, white, or color).

Project 26 Louder Strobe Light




Modify the preceding circuit to be this one, which has the white LED (D6) in parallel with the speaker (SP). Build the circuit and turn on the switch (S1). Adjust the blink rate and sound using the lever on the adjustable resistor (RV), and by pushing the press switch (S2). Project 27 Louder Color Strobe Light

This circuit is louder than the previous circuits because the speaker is in parallel with the LED instead of in series with it. This increases the voltage across the speaker, making it louder.



Use the preceding circuit but replace the white LED (D6) with the red LED (D1) or the color LED (D8).

Project 28 Triple Strobe Light Project 29




Build this circuit and turn on the slide switch (S1). Adjust the blink rate using the lever on the adjustable resistor (RV), and by pushing the press switch (S2).

Note: In rare cases the circuit may not work at all settings on RV. If this happens, move the RV lever to the side near the strobe IC, turn the slide switch off and on to reset the circuit, and only move the RV lever over a small range.

Project 29 Noisy Double Strobe Light

Use the preceding circuit but replace one of the LEDs (D1, D6, or D8) with the speaker (SP).

Project 30 Noisy Triple Strober



Build this circuit and turn on the slide switch (S1). Adjust the blink rate and sound using the lever on the adjustable resistor (RV), and by pushing the press switch (S2).

Note: In rare cases the circuit may not work at all settings on RV. If this happens, move the RV lever to the side near the strobe IC, turn the slide switch off and on to reset the circuit, and only move the RV lever over a small range.


Project 31 Triple Light Noisy Motion Strober

Use the preceding circuit but replace the speaker (SP) with the motor (M1, "+" toward white LED), then place the speaker across the points marked A & B in the drawing. Do not place any fan on the motor.

The LEDs (D1, D6, & D8) flash, the speaker makes noise, and the motor shaft spins or wiggles. Adjust the blink rate, sound, and motor spin using the lever on the adjustable resistor (RV), and by pushing the press switch (S2).


WARNING: Moving parts. Do not touch the fan or motor during operation.

Test Equipment Depot - 800.517.8431 - 99 Washington Street Melrose, MA 02176 TestEquipmentDepot.com



Project 33 2 3 0 0 0 (U22) ۲ COLOR 0 0 0 0 0 0 0 2

-31-



Automatic Light

Build the circuit and turn on the slide switch (S1). Set the lever on the adjustable resistor (RV) so the white LED (D6) just turns off. Slowly cover the phototransistor (Q4) and the white LED brightens. Adjust the light to the phototransistor to turn the white LED on or off.

This is an automatic street lamp that you can turn on at a certain darkness and turn off by a certain brightness. This type of circuit is installed on many outside lights and forces them to turn off and save electricity. They also come on when needed for safety.

You can replace the white LED with the color LED (D8) or the red LED (D1), but you may need to readjust the sensitivity using the lever on RV.


Color Oscillator

This circuit is an oscillator: it uses the color organ to control itself.




Build the circuit as shown, and place one of the LED attachments (tower, egg, or fiber optic tree) over the LED on the Color Organ (U22). Turn on the switch (S1) and watch. The color organ light will change colors on its own.


Dance to the Music



Project 35 Super Dance to the Music



This circuit is similar to the preceding one, but louder and more sensitive. Build the circuit as shown. Connect a music device (not included) to the color organ (U22) as shown, and start music on it, set the volume to mid-range. Place one of the LED attachments over the light on the color organ. Turn on the switch (S1) and SLOWLY ADJUST the lever on the adjustable resistor (RV) for best sound; there will only be a narrow range where the sound is clear. Adjust the volume on your music device for best sound quality.




Build the circuit. Connect a music device (not included) to the color organ (U22) as shown, and start music on it. Place one of the LED attachments over the light on the color organ. Set the lever on the adjustable resistor (RV), and the volume control on your music device, for best sound quality and light effects. The color organ light will "dance" in synch with the music. Compare fast and slow songs, and different loudness levels.


Project 36 Super Dance to the Music (II)

Use the preceding circuit, but remove the 100μ F capacitor (C4). The sound will not be as loud, but will be less distorted. Adjust RV and the volume on your music deice for best sound.

Follow the Music




Build the circuit. Connect a music device (not included) to the color organ (U22) as shown, and start music on it. For best effects, place one of the LED attachments over the light on the color organ. Set the volume control on your music device for best sound quality and light effects. The color organ light will "dance" in synch with the music. Compare fast and slow songs, and different loudness levels.



Color Organ - Headphones



Project 38



Compare the sound quality of using headphones in this circuit, to using the speaker in the preceding circuit.




Build the circuit. Connect a music device (not included) and your own headphones (not included) to the color organ (U22) as shown, and start music on it. For best effects, place one of the LED attachments over the light on the color organ. Set the volume control on your music device for best sound quality and light effects. The color organ light will "dance" in synch with the music.

Output signal to headphones is mono, so you will not hear stereo effects.


MP3

player




Adjustable Light Dance

Build the circuit as shown. For best effects, place one of the LED attachments over the light on the color organ. Turn on the switch (S1) and move the lever on the adjustable resistor (RV) to change the tone of the sound and "speed" of the light.



Suspended Raindrops



Build the circuit as shown. Connect the white LED (D6) to the red & black jumper wires. Turn on the slide switch (S1). Go to a water faucet and adjust the faucet so water is dripping at a steady rate. Dim the room lights and hold the white LED so it shines on the dripping water. Try to set the lever on the adjustable resistor (RV) so that the dipping water drops appear suspended in mid-air. You may need to adjust the drip rate on the faucet to make this work. You may get better results if you replace the 100k Ω resistor (R5) with the 5.1k Ω resistor (R3). Also, try setting the strobe rate to minimum and adjusting the drip rate.

Infrared Detector


TV remote controls transmit a sequence of pulses representing the TV model and the button that was pressed. The U24 infrared detector is just looking any infrared signal.



You need an infrared remote control for this project, such as any TV/stereo/DVD remote control in your home.

Build the circuit and turn on the switch (S1). Point your remote control toward the infrared module (U24) and press any button to activate the red LED (D1).

Sometimes this circuit may activate without a remote control, due to infrared in sunlight or some room lights. If this happens, try moving to a dark room.






Audio Infrared Detector

You need an infrared remote control for this project, such as any TV/stereo/DVD remote control in your home.

Build the circuit, set the lever on the adjustable resistor (RV) all the way towards the infrared module (U24), and turn on the switch (S1). Point your remote control toward the infrared module and press any button to activate an alarm sound. The lever on the adjustable resistor sets how long the alarm plays for, but it only works over a narrow range.


Next, replace the 100Ω resistor (R1) with the $5.1k\Omega$ resistor (R3). The alarm sound is a little different, but the control range on RV is wider.

Sometimes this circuit may activate without a remote control, due to infrared in sunlight or some room lights. If this happens, try moving to a dark room.



Test Equipment Depot - 800.517.8431 - 99 Washington Street Melrose, MA 02176 TestEquipmentDepot.com

Photo Infrared Detector




The phototransistor can detect light, and infrared light is light. The infrared module (U24) is designed to focus only on infrared light.



You need an infrared remote control for this project, such as any TV/stereo/DVD remote control in your home.

Build the circuit and turn on the switch (S1). Place the mounting base (normally used with the fiber optic tree) on the phototransistor (Q4). Set the lever on the adjustable resistor (RV) so the red LED (D1) just turns off; if it never turns off, move away from room lights. Point your remote control directly into the mounting base on Q4, and press any button to activate the red LED (D1).

Project 44 Photo Audio Infrared Detector



You need an infrared remote control for this project, such as any TV/stereo/DVD remote control in your home.

Build the circuit and turn on the switch (S1). Place the mounting base (normally used with the fiber optic tree) on the phototransistor (Q4). Set the lever on the adjustable resistor (RV) so the sound just turns off (if it never turns off, move away from room lights. Point your remote control directly into the mounting base on Q4, and press any button to activate the sound. Project 45 Photo Audio Infrared Detector (II)

Use the preceding circuit, but replace the $0.1\mu F$ capacitor (C2) with the $100\mu F$ capacitor (C4). The circuit works the same way, but the sound stays on longer and is more pleasant.

0

0

01

0

0

00

Hold white LED (D6)

over disc as shown.

0

0

31

Place disc holder onto

the motor as shown.



Build the circuit as shown. Take the colored disc shown and install it into the disc holder, then place the disc holder on the motor (M1). Connect the white LED (D6) to the red & black jumper wires.

For best effects, do this in a dimly lit room. Turn on the slide switch (S1). Push the press switch (S2) until the motor spins continuously (if it stops after you release the press switch, replace your batteries). Hold the white LED upside down over the disc holder so it shines on the spinning disc, and move the lever on the adjustable resistor (RV) slowly while watching the pattern on the spinning disc.

The motor spins the disc so fast that it looks like a blur. However, as you slowly adjust RV the pattern on the disc appears to slow down, stop, and reverse direction. Patterns close to the disc center may be moving at different speeds, or in different directions, from patterns farther from the center! Some patterns may become clear while others are still blurred.

If the motor does not continue spinning after you release S2, then replace your batteries. If it still won't keep spinning then replace the $5.1k\Omega$ resistor (R3) with a 3-snap wire.

OPTIONAL

(Adult supervision required)

The disc holder rests on the motor top loosely and vibrates, making the disc pattern blurry even when the RV setting makes the pattern "stop". The disc patterns will appear clearer if you permanently mount the disc holder to the motor top. This set contains a spare motor top, which can be used for this. This requires removing the motor top from the motor whenever you want to switch from using the disc holder to using the glow fan, so is optional, and requires adult supervision.

If you want to do this, pry the motor top off the motor shaft using a screwdriver.

> Lay the spare motor top in the disc holder upside down, and bond together with glue (glue not included).

After the glue dries, push the modified disc holder on the motor shaft and install a disc cutout. When you want to return to using the glow fan, replace the motor top disc holder with the normal motor top.

Project 47 Slow Strobe Effects

Use the preceding circuit, but replace the 3-snap on the adjustable resistor (RV) with the 100k Ω resistor (R5). The circuit works the same, but the strobe rate is much slower (now you can see the LED flashing), so the strobe effects are different. Slowly adjust the setting on RV as before, and watch the patterns on the spinning disc.

Note: In rare cases the LED may not flash at all settings on RV. If this happens, move the RV lever to the side near the strobe IC, turn the slide switch off and on to reset the circuit, and only move the RV lever over a small range.

Bonus for owners of other Snap Circuits[®] sets: If you have a second 100k Ω resistor (from model SC-100 / 300 / 500 / 750 or other sets), place it directly over the R5 that replaced the 3-snap in the above circuit (and place a 1-snap under one side of the additional R5). Stacking the two 100k Ω resistors together creates a "medium" range of strobe speeds, in between the speeds created with the 3-snap and single 100k Ω . Adjust the RV setting and watch the strobe effects as before.



How does this work? The strobe IC is making the white LED flash so fast that your eyes think it is on continuously. RV sets the flash rate, and at some settings the LED flashes are synchronized with speed of the patterns spinning on the disc, making them appear visible instead of blurred.

When the disc pattern is totally blurred, it will appear as purple, orange, and light green. Combining equal amounts of red & blue makes purple, red & yellow makes orange, and yellow & blue makes green.



R

0

0

0

0

 \odot


U23

Strobe IC

0

6

Project 48 Stable Strobe Effects




The 0.1μ F capacitor has no electrical effect, but it helps to hold the motor in place better and reduce vibrations. Less motor vibration makes the disc holder more stable, and so makes the patterns a little clearer. See if you can notice a difference.

Use the circuits from projects 46 and 47, but add the 0.1μ F capacitor (C2) next to the motor, as shown here. Set the strobe speed so the patterns are visible, and see if they look less blurred than before.



Project 49 Strobe Effects (II)



When the disc pattern is totally blurred, it appears to be white. Combining equal amounts of red, green, and blue makes white. The LED in the color organ IC combines red, green, and blue lights to make white.

Replace the disc in the disc holder with the one shown here, and repeat projects 46-48. Observe the strobe effects. To remove a disc from the holder, use your fingernail, or use a pencil to push it up from beneath one of the tabs.



Project 50 Strobe Effects (III)



Replace the disc in the disc holder with the one shown here, and repeat projects 46-48. Observe the strobe effects. At some RV settings, the rainbow of colors comes into view.

Project 51 Strobe Effects (IV)



Replace the disc in the disc holder with the one shown here, and repeat projects 46-48. Observe the strobe effects. With this pattern, some areas may appear to be moving at different speeds or directions. Sometimes you can see all the colors on the disc, but sometimes you can see all the colors except blue, which is hidden.




Project 52

Replace the disc in the disc holder with the one shown here, and repeat projects 46-48. Observe the strobe effects. This unusual pattern produces several amazing displays at different RV settings.

Project 53 Strobe Effects (VI)


Project 55



Replace the disc in the disc holder with the one shown here, and repeat projects 46-48. Observe the strobe effects. When the disc pattern is totally blurred, it will appear as purple, cyan, and yellow. Combining equal amounts of red & blue makes purple, green & blue makes cyan, and red & green makes yellow.

Project 54 Make Your Own Strobe Effects

Draw your own patterns on paper or cardboard, then cut them to the same size as our discs. You can also draw patterns on the backs of our discs. Put them on the disc holder and repeat projects 46-48. Have a contest with your friends to see who can make the most interesting strobe effects! You can also find lots of fun patterns and visual illusions by doing a search on the internet. There is no limit to what you can do!



Another Strobe Light

This circuit is similar to project 46, and works the same way. Build the circuit as shown. Take one of the colored discs and install it into the disc holder, then place the disc holder on the motor (M1). Connect the white LED (D6) to the red & black jumper wires.


For best effects, do this in a dimly lit room. Turn on the slide switch (S1). Push the press switch (S2) until the motor spins continuously (if it stops after you release the press switch, replace your batteries). Hold the white LED upside down over the disc holder so it shines on the spinning disc, and move the lever on the adjustable resistor (RV) slowly while watching the pattern on the spinning disc.

The motor spins the disc so fast that it looks like a blur. However, as you slowly adjust RV the pattern on the disc appears to slow down, stop, and reverse direction. Patterns close to the disc center may be moving at different speeds, or in different directions, from patterns farther from the center!

If the motor does not continue spinning after you release S2, then replace your batteries. If it still won't keep spinning then replace the $5.1k\Omega$ resistor (R3) with the 100 Ω resistor (R1).

You can reduce the strobe speed by replacing the 3-snap on the adjustable resistor (RV) with the $100k\Omega$ resistor (R5), just as is done in project 48.

Motor Strobe Effects





This project is similar to project 46. Build the circuit as shown. Take one of the colored discs and install it into the disc holder, then place the disc holder on the motor (M1). Connect the white LED (D6) to the red & black jumper wires.

For best effects, do this in a dimly lit room. Turn on the slide switch (S1). Set the lever on the adjustable resistor (RV) down towards the 4-snap. Hold the white LED upside down over the disc holder so it shines on the spinning disc, and move the lever on the adjustable resistor (RV) slowly while watching the pattern on the spinning disc.

The motor spins the disc so fast that it looks like a blur. However, as you slowly adjust RV the pattern on the disc appears to slow down, stop, and reverse direction. Patterns close to the disc center may be moving at different speeds, or in different directions, from patterns farther from the center!


Compare this circuit to the one in project 46. This project changes the strobe effects by using RV to control the motor speed, while project 46 does it by using RV to control the LED flash rate. Getting the best strobe effects by adjusting the motor speed is more difficult, because the motor takes time to adjust its speed, while the LED flash rate adjusts instantly.

Project 57 Motor Strobe Effects (II)

Use the preceding circuit, but replace the 100 Ω resistor (R1) with the 5.1k Ω resistor (R3). The circuit works the same, but the LED flash rate is slower, so the strobe effects are different. Adjust the setting on RV as before, and watch the patterns on the spinning discs.

Project 58 Motor Strobe Effects (III)

Use the preceding circuit, but replace the 5.1k Ω resistor (R3) with the 100k Ω resistor (R5). The circuit works the same, but the LED flash rate is slower (now you can see the LED flashing), so the strobe effects are different. Adjust the setting on RV as before, and watch the patterns on the spinning discs.



LEDs Together

Turn on the slide switch (S1), and compare the brightness of the three LEDs.


Next, remove any of the LEDs and see how the brightness of the others changes.

The voltage needed for an LED to turn on depends on the light color. Red light needs the least, green needs more, but blue and white need the most. The color LED (D8) contains red, green, and blue LEDs.

The R1 resistor reduces the voltage available to the LEDs. The LED brightness varies because some of the LEDs need more voltage than is available. The red LED (D1) will dominate the other colors because it turns on more easily.



Project 60



LEDs Together (II)

Modify the preceding circuit by moving the slide switch (S1) to the location shown here. Compare the brightness of the LEDs. Some LEDs may not turn on.

Next, remove any of the LEDs and see how the brightness of the others changes.

This circuit reduces the voltage to the circuit, because only one set of batteries is connected. The limited battery voltage is split between the R1 resistor and the LEDs. The remaining voltage across the LEDs is enough to activate the red LEDs, but may not be enough to activate the other colors. With the reduced voltage, the red LED will dominate even more than in the preceding circuit.



6

5

0

SWITC

SLIDE SI

2

Brightness Control

Build the circuit and turn on the slide switch (S1). Move the lever on the adjustable resistor (RV) to vary the brightness of the light from the white LED (D6). If desired, you may place any of the LED attachments (tower, egg, or fiber optic tree) on the LED.

Resistors are used to control or limit the flow of electricity in a circuit. Higher resistor values reduce the flow of electricity in a circuit.

In this circuit, the adjustable resistor is used to adjust the LED brightness, to limit the current so the batteries last longer, and to protect the LED from being damaged by the batteries.

What is Resistance? Take your hands and rub them together very fast. Your hands should feel warm. The friction between your hands converts your effort into heat. Resistance is the electrical friction between an electric current and the material it is flowing through.

The adjustable resistor can be set for as low as 200 Ω , or as high as 50,000 Ω (50k Ω).



Project 62

D6

Resistors

$\begin{array}{c} & & \mathbf{R1}_{\odot} \\ \hline 0 \\ 100\Omega \\ \mathbf{RESISTOR} \\ \hline 0 \\ 5.1 \\ \mathbf{K\Omega} \\ \mathbf{RESISTOR} \\ \hline 0 \\ 100 \\ \mathbf{K\Omega} \\ \mathbf{RESISTOR} \\ \end{array}$


Use the circuit built in project 61, but replace the 3-snap with one of the yellow resistors in this set (R1, R3, or R5). Observe how each changes the LED brightness at different settings for the adjustable resistor.

The R1 resistor (100Ω) will have little effect, since it will be dominated by the adjustable resistor. Resistor R5 $(100k\Omega)$ is a high resistance, which greatly restricts the flow of electricity, so the LED will be very dim or off. Resistor R3 $(5.1k\Omega)$ will be in between those.




Project 63Resistors & LEDs

Use the circuits from projects 61 and 62, but replace the white LED (D6) with the red LED (D1) or color LED (D8). Vary the adjustable resistor lever and change the yellow resistors to see how the light varies with each LED.




Project 64 Low Power Brightness Control



Build the circuit and turn on the slide switch (S1). Move the lever on the adjustable resistor (RV) to vary the brightness of the light from the color LED (D8). For best effects, do this in a dimly lit room. At some RV settings the LED will be very dim, and some of its colors may be totally off.

Project 65 Low Power Resistors & LEDs

Use the circuit from project 64, but replace the color LED (D8) with the red LED (D1) or white LED (D6). Vary the adjustable resistor lever to see how the light varies with each LED. The white LED may not be on at all.



Project 66


Persistence of Vision

Build the circuit as shown. Place the black fiber optic cable holder on the white LED (D6) and insert the fiber cable into the black holder as far as it will go. Turn on the slide switch (S1). Take the circuit into a dark room and wave the cable around while watching the loose end. Try it with the lever on the adjustable resistor (RV) at different settings. The light coming out the loose end of the fiber optic cable will separate into short segments or dashes of light.

"Persistence of Vision" works because the light is changing faster than your eyes can adjust. Your eyes continue seeing what they have just seen.

In a movie theater, film frames are flashed on the screen at a fast rate (usually 24 per second). A timing mechanism makes a light bulb flash just as the center of the frame is passing in front of it. Your eyes see this fast series of flashes as a continuous movie.





0

Strobe IC

0



Black

E

Prismatic Film

0

0

This is the same circuit as project 1, but you will view it differently. Turn on the switch (S1), and view the LED through the prismatic film (the clear slide). Prismatic film makes interesting light effects.

Replace the color LED (D8) with the white LED (D6) and red LED (D1): view them through the prismatic film.

Prismatic film separates light into different colors. White light is a combination of all colors.

View different light sources in and around your home through the prismatic film.

Project 68


Look at the

Lights

Project 69 Scattering Light

Use the project 67 circuit, but view the color LED through various semitransparent liquids, glassware, and plastics. Juices, jello, and cloudy glass or plastic work well.


Replace the color LED with the white LED (D6). The white LED is brighter, but does not change color. Semi-transparent materials scatter the light without completely blocking it, so a wide area of the liquid or material is lit up by the light. This happens in the egg and tower LED attachments.





Project 70 Color Fiber Light

Use the circuit from project 67, but place the clear cable holder on the color LED (D8), then place the fiber optic cable into the holder as far as it will go. Turn on the switch, then take the circuit into a dimly lit room and see the light coming out the open end of the cable. The light travels through the cable even as you bend it around.



5

6

One Way Plastic



Side view of base grid


Build the circuit shown, but build it without using the base grid. Turn on the switch (S1) and view the color LED (D8) light through the base grid. Then turn the base grid on its side and try to see through it; you can't.

Try viewing other lights through other clear materials.

The main surface of the base grid is flat and smooth, giving a nice transition for light rays to pass through. If you look closely at the side edges (using a magnifying glass helps), you will see they are slightly curved. These curves, and the angle of the light hitting them, cause more light to be scattered or reflected than light hitting the main surface. Some materials can also pass light better in some directions than in other directions, due to their physical structure.



Project 72 White Blinker



Build the circuit as shown and turn on the switch (S1). Both LEDs are blinking.

The color LED (D8) has a microcircuit that changes the light colors. As it does this, it changes the current through the circuit - which also affects the brightness of the white LED (D6).



Project 73 Red Blinker

Use the preceding circuit, but replace the white LED (D6) with the red LED (D1).


Project 74 Red & White

Use the preceding circuit, but replace the color LED (D8) with the white LED (D6). Both LEDs light, but neither in blinking.

Test Equipment Depot - 800.517.8431 - 99 Washington Street Melrose, MA 02176 TestEquipmentDepot.com

в

Project 75 Color Selector - Red Project 76



Build the circuit as shown. Place the fiber optic tree and mounting base on the color organ (U22). Turn on the switch (S1). The color organ makes a red light. Remove the fiber optic tree and mounting base, and look at the light through the prismatic film.

Color Selector -Green

Use the preceding circuit, but remove the 2-snap between points A & B, and add one between points C & D. Now the color is green. Look at it using the fiber optic tree, and then the prismatic film.

Project 77 Color Selector - Blue

Use the preceding circuit, but remove the 2-snap between points C & D, and add one between points E & F. Now the color is blue. Look at it using the fiber optic tree, and then the prismatic film.

Project 79 Color Selector - Yellow

Use the preceding circuit, but remove the 2-snap between points E & F, and add one between points A & B. Now the color is yellow, which is a combination of red and green. Look at it using the fiber optic tree, and then the prismatic film.

Project 78 Color Selector - Cyan

Use the preceding circuit, but add a 2-snap between points C & D. Now the color is cyan, which is a combination of green and blue. Look at it using the fiber optic tree, and then the prismatic film.

Project 80 Color Selector - Purple


Use the preceding circuit, but remove the 2-snap between points C & D, and add one between points E & F. Now the color is purple, which is a combination of red and blue. Look at it using the fiber optic tree, and then the prismatic film.

Project 81 Color Selector -White

Use the preceding circuit, but add a 2snap between points C & D. Now the color is white, which is a combination of red, green, and blue. Look at it using the fiber optic tree, and then the prismatic film.

Black is made by turning off all the colors.

Project 82 LED Color Spectrum



Build the circuit as shown, and turn on the switch (S1). The white LED (D6) will be on. Look at the white LED through the prismatic film to see the color spectrum of white light, which is all the colors of a rainbow. For best effects, do this in a dimly lit room.

Now remove the 2-snap across points W-W, and place it across points C-C (the color LED), then points R-R, G-G, and B-B (for the color organ). Using the prismatic film, look at the color spectrum produced by the color LED, and the different colors from the color organ. Compare them to the white LED spectrum.

Project 83 LED Color Spectrum (II)

Use the preceding circuit, but remove the 2-snap across points W-W and place 2-snaps across R-R and G-G. Use the prismatic film to look at the color spectrum. View from different directions and different angles.

Next, move the 2-snaps to R-R and B-B, and look at the spectrum. Then move the 2-snaps to G-G and B-B and look at the spectrum. View from different directions and different angles.

For each combination, the color spectrum should be mostly light of the 2 individual colors you are combining.

Project 84 LED Color Spectrum (III)

Use the preceding circuit, but place 2-snaps across points R-R, G-G, and B-B. Use the prismatic film to look at the color spectrum. View from different directions and different angles.

With the above connections, the color organ (U22) produces white light. The actual color spectrum you see will vary with your viewing angle, because the light is produced using separate red, green, and blue LEDs next to each other.

Now remove the 2-snaps from R-R, G-G, and B-B, and place one across W-W, so the circuit is like the project 82 drawing. Use the prismatic film to view the color spectrum from the white LED (D6) again, and compare it to the white light spectrum from U22. The D6 spectrum does not vary as much with the viewing angle because the light is produced by a single LED, and it is brighter.

LED Color Spectrum (IV)

Use the circuit combinations from projects 82-84, but look at the different lights through the red, green, or blue filters instead of the prismatic film. Each filter only allows you to see light of that color, and blocks the other colors. If you put all three filters together then all light is blocked.


Actually, the red filter will pass a little of the green light, the blue filter will pass a little of the green light, and the green filter will pass a little of the green and blue light. This is because green light is between red and blue light in the color spectrum, and the filters are not perfect. See page 13 for more information about the color spectrum.

Project 86 LED Color Spectrum (V)

Repeat project 82, but place the black fiber optic cable holder with the fiber optic cable on the LED you want to view. Look at the light coming out the other end of the cable using the prismatic film, and view in a dimly lit room. The light is not as bright but the beam is narrower, so the color spectrum may be clearer.

-47-

Project 87 Blinking Beeping



Build the circuit as shown and turn on the switch (S1). The color LED (D8) will be blinking and you hear beeping from the speaker. The sound will not be very loud.

0

0


0

The color LED (D8) has a microcircuit that changes the light colors. As it does this, it changes the current through the circuit. The transistor (Q2) amplifies the changing current and uses it to control the speaker (SP).

Project 88 Blinking Blinking

Use the preceding circuit, but replace the speaker with the red LED (D1). Now the red LED will also be blinking.

Project 89 Blinking Control




Build the circuit as shown and turn on the switch (S1). The color LED (D8) and white LED (D6) will both be blinking. The color LED will be brighter than in the preceding circuit.

The white LED is controlled by the color LED using the transistor (Q2). If you remove the color LED from the circuit then the white LED will not blink.

Project 90 Blinking Control Beeping

Use the preceding circuit, but replace the white LED (D6) with the speaker (SP). Now the blinking LED controls a beeping sound, but the sound will not be very loud.


Triple Blinker



Build the circuit as shown and turn on the switch (S1). Three LEDs (D1, D6, and D8) will be blinking.

The red and white LEDs are controlled by the color LED using the transistor (Q2). If you remove the color LED from the circuit then the other LEDs will not blink.

Project 92 Funny Speed Motor



WARNING: Moving parts. Do not touch the fan or motor during operation.

Build the circuit as shown and turn on the switch (S1). The color LED (D8) is blinking and the motor (M1) spins at different speeds. Try this circuit with the glow fan on the motor, and without the fan.

The motor is controlled by the color LED using the transistor (Q2). If you remove the color LED from the circuit then the motor will not spin.


In this circuit the color LED is powered by one set of batteries, and the motor is powered by different set. This was done because the motor produces electrical pulses as it spins, and these pulses can confuse the color LED.



Project 93 Funny Speed Motor with Light

Use the preceding circuit, but add the red LED (D1) across points A & B ("+" to A). This adds another blinking light.

Light Dance Audio Override



6

2

SP SPEAKE

⊙<u>≃</u> 2

2

0

01

0

6

2 0

0

0

1

5

0

0

0

0

0

0

3

6

0

Build the circuit, which is similar to project 34 (Dance to the Music). Connect a music device (not included) to the color organ (U22) as shown, and start music on it. Place one of the LED attachments over the light on the color organ. Set the lever on the adjustable resistor (RV), and the volume control on your music device, for best sound quality and light effects. The color organ light will "dance" in synch with the music.

For the next part, you need the color organ light to be changing slowly. Set your music device to play a song with a slow beat, and set the volume control on it so the sound is not very loud.

Now blow on the microphone (X1) or talk loud directly into it. The dancing light pattern should be interrupted by your blowing/talking. If you don't notice any difference then lower the volume control on your music device. Songs with a slower beat work best for this.

Project 95

0

0

0

0

0

0

0

C

D.O

E

F (O

0

0

LED Attachments

MP3

player

j,

Project 94


Light Dance Light Override

Build the circuit, which is similar to project 34 (Dance to the Music). Connect a music device (not included) to the color organ (U22) as shown, and start music on it. Place one of the LED attachments over the light on the color organ. Cover the phototransistor (Q4) with your hand and set the lever on the adjustable resistor (RV), and the volume control on your music device, for best sound quality and light effects. The color organ light will "dance" in synch with the music.

Uncover the phototransistor and shine a bright light on it. The color organ light will stop changing until you re-cover the phototransistor. The music will not be affected.

Test Equipment Depot - 800.517.8431 - 99 Washington Street Melrose, MA 02176 TestEquipmentDepot.com

Counting Light




The color organ is counting how many times light turns the phototransistor on or off. At some count levels, the color organ changes colors.



Build the circuit as shown and turn on the switch (S1). Place one of the LED attachments over the LED on the color organ (U22). Connect the color LED (D8) using the red & black jumper wires and hold it just above the phototransistor (Q4), so that it shines directly into the phototransistor. For best effects, do this in a dimly lit room. Every few seconds, the color organ light will change colors.


Project 97

Adjustable Counting Light



Build the circuit as shown and turn on the switch (S1). Place one of the LED attachments over the LED on the color organ (U22). Connect the white LED (D6) using the red & black jumper wires and hold it just above the phototransistor (Q4), so that it shines directly into the phototransistor. For best effects, do this in a dimly lit room. The color organ light will change colors, the lever on the adjustable resistor (RV) controls how fast the colors change.


Bright Off Light



Build the circuit as shown and turn on the switch (S1). Place the circuit in a dark room or cover the phototransistor (Q4); the color LED (D8) should be on. Shine light on the phototransistor and the color LED turns off.

Project 99

R/C Blink & Beep



You need an infrared remote control for this project, such as any TV/stereo/DVD remote control in your home.

Build the circuit and turn on the switch (S1). Point your remote control toward the infrared module (U24) and press any button to activate the red LED (D1) and speaker (SP).

Sometimes this circuit may activate without a remote control, due to infrared in sunlight or some room lights. If this happens, try moving to a dark room.

IDESI

0

012

SWITCH

0

0

5

5.1KΩ RESIST

0

D6

C4

0

0

0

0

BO


CO

D

E-

F





Now push the press switch (S2); the white LED (D6) turns on and stays on. The white LED will stay on until you turn off the slide switch.

The two transistors act as an electronic device called an SCR (Silicon Controlled Rectifier). An SCR is a three-pin device that once its control pin is triggered, remains on until the current flow through it stops.




Use the preceding circuit, but replace the 100Ω resistor (R1) with the color LED (D8) or the red LED (D1).

Stuck On

Lights



RESISTOR



Build the circuit as shown, and note that several parts are stacked over others. Turn on the slide switch (S1); nothing happens.

Now push the press switch (S2); the motor (M1) turns on and stays on. The motor will stay on until you turn off the slide switch.

WARNING: Moving parts. Do not touch the fan or motor during operation.

Project 103 Low Voltage Stuck On Lights

Use the preceding circuit, but replace the motor with the red LED (D1).

Project 104 Stuck On Motor & Lights

Use the project 102 circuit but place the red LED (D1) next to the motor at base grid locations G5-G7 ("+" to G5). Connect the red LED to the adjacent points on the motor using the red & black jumper wires, making sure the jumper wires do not touch the motor or fan.

Turn on the slide switch (S1), then push the press switch (S2). The motor spins and the red LED is dim. Turn off the circuit, remove the fan from the motor, and turn the circuit back on. Now the red LED is bright because it takes less electricity to spin the motor without the fan, leaving more electricity for the red LED.

Project 105 Funky Light & Sound

SLIDE SI SWITCH

0 2

0

0

0

Project 106


Use the preceding circuit, but replace the color LED (D8) with the $100k\Omega$ resistor (R5) or the $5.1k\Omega$ resistor (R3).

Project 107 Light & Motion

Repeat projects 105 & 106 but replace the speaker with the motor (M1) and glow fan (motor "+" toward S1).

WARNING: Moving parts. Do not touch the fan or motor during operation.

Project 108 Adjustable Light & Sound



0

2 0

0 6 0

0-

0

0

0

0

U23

0

0

0

0

2

Strobe IC 💿

в

С

D -

E -

Modify the preceding circuit to match the one shown here. Use the lever on the adjustable resistor (RV) to control the light & sound. At some settings the white LED (D6) will not light, or will appear to be on continuously.

Build the circuit as shown and turn on the switch

(S1). The color LED (D8)

is used to control the


strobe IC (U23), producing

unusual effects.

Project 109 Adjustable Light & Motion

Use the preceding circuit, but replace the speaker with the motor (M1) and glow fan (motor "+" toward S1).






Blinking Step Motor

Build the circuit as shown and turn on the switch (S1). The color LED (D8) is used to control the strobe IC (U23), which turns on the motor (M1) in short bursts.

To have 3 LEDs, place the red LED (D1) directly over the white LED (D6).


Project 111



Blink Step Beep


Build the circuit as shown and turn on the switch (S1). The color LED (D8) is used to control the strobe IC (U23), which turns on the motor (M1), white LED (D6), and speaker (SP) in short bursts. The circuit also works without the fan on the motor.

If you replace the motor with the black jumper wire, the white LED will be a little brighter.




Project 112 Day Blinker

Project 113 Night Blinker



Build the circuit as shown and turn on the switch (S1). The color LED (D8) is on when there is light on the phototransistor (Q4). Shine light on or cover the phototransistor to turn the color LED on or off.




Build the circuit as shown and turn on the switch (S1). The color LED (D8) is off when there is light on the phototransistor (Q4). Cover or shine light on the phototransistor to turn the color LED on or off.

If the color LED comes on too easily, reduce the sensitivity by replacing the $5.1k\Omega$ resistor (R3) with the $100k\Omega$ resistor (R5).

Project 114

Night Light Show

LED Attachments




Build the circuit as shown. Connect a music device (not included) to the color organ (U22) as shown, and start music on it. Place one of the LED attachments over the light on the color organ. Turn on the switch (S1), then cover the phototransistor (Q4) to see a light show. Adjust the volume on your music device for best light effects.

Replace the $100k\Omega$ resistor (R5) with the $5.1k\Omega$ resistor (R3) to make the light brighter.

Project 115 Daylight Light Show

Use the preceding circuit, but swap the locations of the phototransistor (Q4) and the 100k Ω resistor (R5), put the "+" side of Q4 towards the NPN transistor (Q2). Now covering the phototransistor turns off the light show.

Buzzer



This circuit is an oscillator, which uses feedback to control the pitch of the sound.

Build the circuit as shown and turn on the switch (S1). Move the lever on the adjustable resistor (RV) to vary the pitch of the buzzing sound.

Project 117 Higher Pitch Buzzer

Use the preceding circuit, but place the $5.1k\Omega$ resistor directly over the $100k\Omega$ resistor using a 1-snap. The pitch of the tone is higher now, but the circuit may not make noise on all settings for the adjustable resistor.

Project 118 Photo Light & Motion


Use the circuits from projects 116-117, but add the phototransistor (Q4) across base grid locations B2-B4 (between RV and R1, "+" on the left), on level 3. Vary the amount of light on the phototransistor to change the sound, while also varying RV.

Project 119 Slow Light & Motion

Use the circuits from projects 116-117, but replace the 0.1μ F capacitor (C2) with the 100μ F capacitor (C4), "+" to the right. Turn the switch on and patiently wait. The speaker will beep and the color LED (D8) will flash every 5-20 seconds, depending on the resistors.

Project 120

Light Up the Fan




Build the circuit as shown, place the glow fan on the motor (M1), and turn on the slide switch (S1). Place the circuit in a dark room and push the press switch (S2) to spin the fan. The color LED (D8) lights up the spinning fan.

The circuit with the color LED is not electrically connected to the circuit with the motor. This was done because the motor produces electrical pulses as it spins, and these pulses can confuse the color LED.

WARNING: Moving parts. Do not touch the fan or motor during operation.



Project 121 High Power Buzzer



Build the circuit as shown and turn on the switch (S1). Move the lever on the adjustable resistor (RV) to vary the pitch of the buzzing sound. The motor (M1) may not spin.

Project 122 Buzz Fan

Use the preceding circuit, but place the $5.1k\Omega$ resistor (R3) directly over the $100k\Omega$ resistor (R5) using a 1-snap. The pitch of the tone is higher now, and the fan spins. The circuit may not make noise on all settings for the adjustable resistor. The motor may not spin.

Project 123 Photo Buzzer

Use the circuits from projects 121-122, but add the phototransistor (Q4) across base grid locations B2-B4 (between RV and R1, "+" on the left), on level 3. Shine a bright light on the phototransistor to change the sound, while also moving the lever on RV.

You can also place the phototransistor directly over the $100k\Omega$ resistor, as done for the $5.1k\Omega$ resistor in project 122. For this arrangement, "+" on Q4 should be on the right.

Project 124 Step Beeper

operation.

WARNING: Moving parts. Do not


touch the fan or motor during

Use the circuits from projects 121-123, but replace the 0.1μ F capacitor (C2) with the 100μ F capacitor (C4), "+" to the right. The motor will move in small bursts, with long intervals or almost continuously, depending on the resistors and phototransistor.

Next, replace the color LED (D8) with the white LED (D6). See how the circuit works now.

Project 125 Wacky Buzzer

Repeat projects 121-123, but add the 100μ F capacitor (C4) across the points marked A & B in the drawing ("+" to A). The motor may not spin but the sound is different. The sound may not be very loud.



Fiber Fun Project 127

Build the circuit as shown. Place the clear cable holder on the color LED (D8) and the black cable holder on the phototransistor (Q4), then place the fiber optic cable into the holders as far as it will go.

Turn on the slide switch (S1). Light is transmitted from the color LED, through the fiber optic cable, to control the NPN transistor (Q2) and red LED (D1).


You can replace the red LED with the white LED (D6), but the white LED may be dim or not light.

Project 127 Fiber Fun Backwards

Use the preceding circuit but swap the locations of the phototransistor (Q4) and the $100k\Omega$ resistor (R5), keep the "+" side of Q4 in the same direction. Now the red LED will be on whenever the color LED is off.

Project 128

Black -59-



More Fiber Fun

Build the circuit as shown. Place the clear cable holder on the color LED (D8) and the black cable holder on the phototransistor (Q4), then place the fiber optic cable into the holders as far as it will go. For best performance the fiber optic cable should stand straight up in the holders, without bending them.

Turn on the slide switch (S1). Light is transmitted from the color LED, through the fiber optic cable, to control the PNP transistor (Q1) and red LED (D1). The speaker is used to help limit the current through the color LED, and will not make noise.

For more fun, swap the locations of the color LED (D8) and red LED (D1). You may also replace either LED with the white LED (D6), but the white LED may be dim or not light.

Project 129 Other Fiber Fun

Use the preceding circuit but swap the locations of the phototransistor (Q4) and the 100k Ω resistor (R5), keep the "+" side of Q4 in the same direction. Now the red LED will be on whenever the color LED is on.

Morse Code

Build the circuit as shown. Place the clear cable holder on the red

LED (D1) and the black cable holder on the phototransistor (Q4),

then place the fiber optic cable into the holders as far as it will go. For best performance the fiber optic cable should stand straight up in the holders, without bending them. Turn on the slide switch

(S1), then push the press switch (S2) several times to send secret messages between the circuits using Morse Code. If your fiber

optic cable was a lot longer, you could use this circuit to send


messages to your friends in different cities. The speaker is used to help limit the current through the red LED, and will not make

If desired, you can swap the locations of the red and white LEDs

Note: If the white LED (D6) does not light or is dim, replace it with the color LED (D8). The white LED can be brighter and won't

0

0



Morse Code: The forerunner of today's telephone system was the telegraph, which was widely used in the latter half of the 19th century. It only had two states - on or off (that is, transmitting or not transmitting), and could not send the range of frequencies contained in human voices or music. A code was developed to send information over long distances using this system and a sequence of dots and dashes (short or long transmit bursts). It was named Morse Code after its inventor. It was also used extensively in the early days of radio communications, though it isn't in wide use today. It is sometimes referred to in Hollywood movies, especially Westerns. Modern fiber optics communications systems send data across the country using similar coding systems, but at much higher speeds.

change colors, but requires higher voltage to activate. **MORSE CODE** N 2.5 Period 0 Comma Ρ Question ..__. Q __._ .____ R 2 1.2.1 ..___ S .._. 3 · · · _ _ _ 4 1.1.1 _ · · · · _ _ U 5 1. A. S. A. A. V 6 _ W 1.2.2 ____. Х 8 11 A 11 A ____. 9 1. A. L. L. 0

noise.

(D1 & D6).

Project 131

Fiber Shut-Off

Use the preceding circuit but swap the locations of the phototransistor (Q4) and the 100k Ω resistor (R5), keep the "+" side of Q4 in the same direction. Now pushing the press switch will turn off the LED in the right half of the circuit.

Α

В

D

Е

F

G

Н


J

K

L


Μ

Blow On Fiber



Build the circuit as shown. Place the clear cable holder on the color LED (D8) and the black cable holder on the phototransistor (Q4), then place the fiber optic cable into the holders as far as it will go. For best performance the fiber optic cable should stand straight up in the holders, without bending them.

Turn on the slide switch (S1), and blow on the microphone or talk loudly into it. The signal from the microphone will be sent through the fiber optic cable to the right half of the circuit, to activate the red LED (D1).




Fiber Music

Build the circuit as shown. Place the clear cable holder on the color organ (U22) and the black cable holder on the phototransistor (Q4), then place the fiber optic cable into the holders as far as it will go. For best performance the fiber optic cable should stand straight up in the holders, without bending them.The clear holder will be a loose fit.

Connect a music device (not included) to the color organ as shown, and start the music on it. The music plays on the speaker (SP) while the LED on the color organ controls the red LED (D1) through the fiber optic cable. Set the volume control on your music device for best light & sound effects.

Fiber Color Organ




Build the circuit as shown. Place the clear cable holder on the color organ (U22) and the black cable holder on the phototransistor (Q4), then place the fiber optic cable into the holders as far as it will go. For best performance the fiber optic cable should stand straight up in the holders, without bending them. The clear holder will be a loose fit.

Turn on the slide switch (S1), and blow on the microphone or talk loudly into it. The signal from the microphone will change the LED on the color organ, then send the light through the fiber optic cable to the phototransistor, which controls the red LED (D1).

Optional: Connect a music device (not included) to the color organ as shown, and start the music on it. The music device will control the red LED. Set the volume control on your music device for best light effects. If you replace the red LED with the speaker (SP), then you get sound effects (beeping, not music).

Project 135



Bright Fiber Color Organ


Build the circuit as shown. Place the clear cable holder on the color organ (U22) and the black cable holder on the phototransistor (Q4), then place the fiber optic cable into the holders as far as it will go. For best performance the fiber optic cable should stand straight up in the holders, without bending them. The clear holder will be a loose fit.

Turn on the slide switch (S1), and blow on the microphone or talk loudly into it. The signal from the microphone will change the LED on the color organ, then send the light through the fiber optic cable to the phototransistor, which controls the white LED (D6).

Optional: Connect a music device (not included) to the color organ as shown, and start the music on it. The music device will control the white LED. Set the volume control on your music device for best light effects.

Motor Power | Project 137

0




Build the circuit as shown, push the press switch (S2), and look at the brightness of the red LED (D1). Try it three ways: with no fan on the motor, with the glow fan on the motor, and keeping the motor from spinning with your fingers. When the motor is spinning, you will hear noise from the speaker (SP).

The motor needs a lot of electricity to start spinning, but needs less the faster it is spinning. When kept from spinning by your fingers, the motor sucks up all the electricity, leaving none to light the red LED. With the fan on the motor, the LED gets enough electricity to light. When the motor is spinning without the fan, the LED gets lots of electricity and is bright.

WARNING: Moving parts. Do not touch the fan or motor during operation.

Project 138



itch LED otor, the the the the the

The color and white LEDs need more electricity to light than the red LED. The motor "noise" that you hear on the speaker can also confuse the color LED and disrupt its color pattern.

0

Reflection Detector

Build the circuit as shown and turn on the switch (S1). Place the mounting base over the phototransistor (Q4). Set the lever on the adjustable resistor (RV) all the way toward the NPN transistor (Q2). Move the circuit into a dimly lit room, so that the color LED (D8) is off.

Place a mirror directly over the white LED (D6) and photo-transistor (Q4), or hold it facing a wall mirror. When enough light from the white LED reaches the phototransistor, the color LED will turn on, indicating that a reflection has been detected.

The mounting base is used to block direct light from the white LED to the phototransistor, and to shield the phototransistor from room light. If your room is very dark, you may get better results by placing the mounting base over the white LED instead of the phototransistor.

Project 139 Cup & String Communication


Light, radio signals, and sound all travel through air like waves travel through water. To help you understand how they are like waves, you can make a cup & string telephone. This common trick requires some household materials (not included with this kit): two large plastic or paper cups, some non-stretchable thread or kite string, and a sharp pencil. Adult supervision is recommended.

Take the cups and punch a tiny hole in the center of the bottom of each with a sharp pencil (or something similar). Take a piece of string (use between 25 and 100 feet) and thread each end through each hole. Either knot or tape the string so it cannot go back through the hole when the string is stretched. Now with two people, have each one take one of the cups and spread apart until the string is tight. The key is to make the string tight, so its best to keep the string in a straight line. Now if one of you talks into one of the cups while the other listens, the second person should be able to hear what the first person says.


How it works: When you talk into the cup, the cup bottom vibrates back and forth from your sound waves. The vibrations travel through the string by pulling the string back and forth, and then make the bottom of the second cup vibrate just like the first cup did, producing sound waves that the listener can hear. If the string is tight, the received sound waves will be just like the ones sent, and the listener hears what the talker said.

Telephones work the same way, except that electric current replaces the string. In radio, the changing current from a microphone is used to encode electromagnetic waves sent through the air, then decoded in a listening receiver.





Project 140 Slow Motor Speed Control



The motor needs a lot of electricity to start spinning, but needs less the faster it is spinning. The resistors (R1 & RV) are limiting how much electricity flows, so the motor can barely spin.



Build the circuit as shown; do not place the fan on the motor. Set the lever on the adjustable resistor (RV) toward the 3-snap. Turn on the switch (S1) to start the motor (M1). If the motor does not spin, then give it a push to get it started. Use the lever on the adjustable resistor to control the motor speed. If the motor does not spin even after giving it a push then replace your batteries.

Turn off the switch and turn the motor shaft counterclockwise with your fingers. Now turn the switch on try turning the motor counterclockwise; now it is harder because the circuit is trying to turn the motor clockwise at the same time.

Project 141 Slow Motor Start Aid


Use the preceding circuit but add the 100μ F capacitor (C4) directly over the 100Ω resistor (R1), "+" side towards the motor. The circuit works the same, but starts more easily.

If you have a larger 470 μ F capacitor (C5), which is included with some other Snap Circuits[®] sets, then you can use it in place of the 100 μ F capacitor. It will make the motor start even more easily.

3

The capacitor allows a short surge of electricity to flow through it until it charges up. This short surge bypasses the higher resistance of the resistors, and helps the motor get going.

Project 142



R/C Motor

You need an infrared remote control for this project, such as any TV/stereo/DVD remote control in your home.

Build the circuit and turn on the switch (S1). Point your remote control toward the infrared module (U24) and press any button to spin the motor (M1).

Next, remove the 100μ F capacitor (C4). The circuit woks the same, except now the motor moves in small steps.


Sometimes this circuit may activate without a remote control, due to infrared in sunlight or some room lights. If this happens, try moving to a darker room.



Test Equipment Depot - 800.517.8431 - 99 Washington Street Melrose, MA 02176 TestEquipmentDepot.com

Series Lights

Wacky Sound Control



This circuit has all the parts connected in a series. Swapping the locations of any parts in the circuit (without changing the direction of their "+" side) will not change how the circuit works. Try it.


The LEDs are dim because the batteries need to overcome the activation voltage level for every LED in the series before any can light. That doesn't leave much voltage to overcome the resistance in the circuit. If you replace one of the LEDs with a 3-snap, the others will be much brighter. Try it.



Build the circuit and turn on the switch (S1). Place the circuit in a dimly lit room. Some of the LEDs (D1, D6, & D8) will be blinking, but none will be very bright. If nothing lights then replace your batteries.


The LEDs are blinking because a colorchanging circuit in the color LED is turning that LED on and off, which also affects the other LEDs.

Project 144



Build the circuit and turn on the slide switch (S1). Vary the amount of light on the phototransistor (Q4) and push the press switch (S2) to change the sound.

Musical Shapes



Build the circuit and turn on the switch (S1). Make your parts using either the water puddles method (A), the drawn parts method (B), or the pencil parts method (C). Touch the metal in the jumper wires to your parts and read the current.

0

0

0

0

0

6

The black core of pencils is graphite, the same material used in the resistors in the pivot stand.

Method A (easy): Spread some water on the table into puddles of different shapes, perhaps like the ones shown here. Touch the jumper wires to points at the ends of the puddles.



Method B (challenging): Use a SHARP pencil (No. 2 lead is best) and draw shapes, such as the ones here. Draw them on a hard, flat surface. Press hard and fill in several times until you have a thick, even layer of pencil lead. Touch the jumper wires to points at the ends of the drawings. You may get better electrical contact if you wet the metal with a few drops of water. Wash your hands when finished.

Method C (adult supervision and permission required): Use some double-sided pencils if available, or VERY CAREFULLY break a pencil in half. Touch the jumper wires to the black core of the pencil at both ends.





Use the preceding circuit but touch the metal in the jumper wires snaps with your fingers. Wet your fingers for best results. Your fingers will change the sound, because your body resistance is less than the $100k\Omega$ resistor (R5) in the circuit.

Next, place the loose ends of the jumper wires in a cup of water, make sure the metal parts aren't touching each other. The water should change the sound.

Now add salt to the water and stir to dissolve it. The sound should have higher pitch now, since salt water has less resistance than plain water.

Don't drink any water used here.

Project 147 **Human & Liquid Light**


Build the circuit and turn on the switch (S1). Touch the metal in the jumper wire snaps with vour fingers. Use the lever on the adjustable resistor (RV) to adjust the sensitivity of the circuit. You may see a difference in the light brightness just by pressing the contacts harder with your fingers.

Next, place the loose ends of the jumper wires in a cup of water, make sure the metal parts aren't touching each other. The water should change the light brightness. Readjust sensitivity usina RV.

Now add salt to the water and stir to dissolve it. The light should be brighter, since salt water has less resistance than plain water. Readjust sensitivity using RV.

Don't drink any water used here.

0



Project 149

Blow On the Light


The microphone is a resistor that changes in value due to changes in air pressure on its surface.




Build the circuit and turn on the slide switch (S1). Set the lever on the adjustable resistor (RV) to the top. If the white LED (D6) is on, move the lever on RV until the LED just shuts off. Now blow on the microphone (X1) to turn the white LED on.

Blow Off the Light

Build the circuit and turn on the slide switch (S1). Wait for the white LED (D6) to come on. Blow into the microphone (X1) to make the white LED flicker. If you blow hard enough, the LED will turn off for a moment.






Transistor

Build the circuit and turn on the slide switch (S1). Slowly move the lever on the adjustable resistor (RV) across its range while watching the brightness of the red & white LEDs (D1 & D6).

Transistors, such as the NPN transistor (Q2), can amplify electric currents. In this circuit, the adjustable resistor controls a small current going to the transistor through the red LED. The transistor uses this small current to control a larger current through the white LED. At some RV settings, the control current is too small to light the red LED, but the transistor-amplified is large enough to light the white LED.



Project 151



The PNP transistor (Q1) is just like the NPN transistor (Q2), except that the currents flow in opposite directions.


0

0

Another Transistor

This circuit is just like the preceding one, except uses a different type of transistor. Build the circuit and turn on the slide switch (S1). Slowly move the lever on the adjustable resistor (RV) across its range while watching the brightness of the red & white LEDs (D1 & D6).

Project 152 Charging & Discharging Project 153



Turn on the slide switch (S1) for a few seconds, then turn it off. The red LED (D1) is dimly lit for a few moments but goes completely dark as the batteries (B1) charge up the 100µF capacitor (C4). The capacitor is storing electrical charge.

Now press the press switch (S2) for a few seconds. The white LED (D6) is initially bright but goes dim as the capacitor discharges itself through it.


The C4 capacitor value (100µF) sets how much charge can be stored in it, and the R3 resistor value $(5.1k\Omega)$ sets how quickly that charge can be stored or released.

Now swap the locations of the white & red LEDs, and try the circuit again. Both LEDs have the same electrical current flowing through them, but white LED is much brighter than the red LED because it is a super-bright LED while the red one isn't.

Mini Capacitor


Use the project 152 circuit but replace the 100µF capacitor (C4) with the $0.1\mu F$ capacitor (C2). The circuit works the same, but the LEDs will only light very briefly, because the smaller 0.1µF capacitor stores much less electricity than the larger 100uF capacitor.

Project 154



Adjustable **Charging & Discharging**

Modify the project 152 circuit to be this one. which the has adjustable resistor (RV) instead of the 5.1k Ω resistor (R3). Use the lever on RV to adjust the capacitor charge & discharge rate, setting it towards the red LED (D1) will make the LEDs flash brighter but get dim faster.




This circuit is similar to the preceding one, but may be easier to understand. Set the lever on the adjustable resistor (RV) towards the 100µF capacitor (C4). Place the white LED (D6) across the points marked B & C; the LED lights as the capacitor charges. Next, place the white LED across points A & B instead; now the LED lights as the capacitor discharges. Move the white LED back to B & C and repeat. Use the lever on RV to vary the charge / discharge rate.

The capacitor is storing energy like a mini battery.



Test Equipment Depot - 800.517.8431 - 99 Washington Street Melrose, MA 02176 TestEquipmentDepot.com

Project 156 Photo Current Amplifier Project 157



Build the circuit, turn on the switch (S1), and vary the amount of light on the phototransistor (Q4) using your hand. Compare the brightness of the white LED (D6) and color LED (D8).

Swap the locations of the white and color LEDs, and compare the brightness now.

The NPN transistor (Q2) is a current amplifier. When a small current flows into Q2 through the left branch (through Q4), a larger current will flow into Q2 through the right branch (with R1). **Green arrows shown the current flow.** So the LED on the right side will be brighter than the LED on the left side. The current in the right branch might be 100 times larger than in the left branch.




Project 157 LEDs & Transistors

Use the preceding circuit but replace either LED (D6 or D8) with the red LED (D1). Compare all three LEDs, in both locations.

LED brightness depends on the materials used, construction quality, and the current through it. The white LED is super-bright, the red LED is low-brightness, and the color LED is between the others.



PNP Amplifier




The PNP transistor (Q1) is just like the NPN transistor (Q2), except that the currents flow in opposite directions. Green arrows shown the current flow.



This circuit is just like the preceding one except it uses a different type of transistor. Build the circuit, turn on the switch (S1), and vary the amount of light on the phototransistor (Q4) using your hand. Compare the brightness of the white LED (D6) and color LED (D8).

Replace either LED (D6 or D8) with the red LED (D1). Compare all three LEDs, in both locations.






press switch (S2). Turn on the slide switch (S1), and push the press switch. The color LED (D8) will light for a while and then slowly turn off. The brighter the light on the phototransistor (Q4), the shorter the color LED stays on.

Set the lever on the adjustable resistor (RV) all the way towards the

You can replace the color LED with the red LED (D1) or the white LED (D6).

Project 160

Resistance Director



The adjustable resistor can be adjusted from about 200 ohms to about 50,000 ohms.


The white LED is a super-bright LED, so will be brighter than the others at comparable resistance.



Move the lever on the adjustable resistor (RV) across its range and watch the brightness of the white and color LEDs (D6 & D8).

Replace either LED with the red LED (D1) and compare it too.

You can also replace one of the battery holders (B1) with a 3-snap wire, and compare the LED brightnesses at lower voltage.



Resistors are used to control the amount of current through a circuit. Increasing the resistance decreases the current.



Turn on either or both switches (S1 & S2) and compare the white LED (D6) brightness.

This circuit has the 100Ω resistor (R1), the 5.1k Ω resistor (R3), and the $100k\Omega$ resistor (R5) arranged in series. The switches are used to bypass the larger resistors. The largest resistor controls the brightness in this arrangement.

Project 162


Current Controllers -Parallel

Current Controllers -

Series

Turn on either or both switches (S1 & S2) and compare the white LED (D6) brightness.

This circuit has the 100Ω resistor (R1), the 5.1k Ω resistor (R3), and the $100k\Omega$ resistor (R5) arranged in parallel. The switches are used to disconnect the smaller resistors. The smallest resistor controls the brightness in this arrangement.



0

6

 (\odot)

U23 Strobe IC 💿

R3_@

0

0

0

2

0

0

0

,0

0

SPEAKE

SP

2

0

0

0

Blow Sound Changer

When you turn on the switch (S1), you hear a siren sound. Blow into the microphone (X1) to change the sound.

RV is used as a fixed resistor (50k Ω): so moving its control lever will have no effect.

Project 164

0

00KΩ RESIST

0)

0

02

6

O

3 0

0

D

E

0

01

0 4

0

0

BO

0

DO

E(O

0

0

0

RV

3


0

0 5

0

0

The light is on while the 100µF capacitor (C4) is charging, and shuts off when the capacitor gets fully charged. Pressing S2 discharges the capacitor. The charge-up time is set by the capacitor's value and resistors R5 and RV.





Build the circuit, turn on the slide switch (S1), and push the press switch (S2). The white LED (D6) is on for a while and then shuts off. Turning S1 off and back on will not get the light back on. Push S2 to get the light back on.

Short Light

Replace the white LED with the color LED (D8) to change the light style.


RV is used as a fixed resistor (50k Ω); so moving its control lever will have no effect.

Project 165 Shorter Light

Use the preceding circuit but replace the 100k Ω resistor (R5) with the smaller $5.1k\Omega$ resistor (R3). Now the light doesn't stay on as lona.

Project 166 Photo Light Control

Project 167 Air Pressure Light Control



Project 168

2

0

011

0

E

0

0

0

2

0

0


0

0 0 (\bigcirc) E

Blow on the microphone (X1). The white LED (D6) will flicker. because the resistance of the microphone changes when you blow on it.

Talking into the microphone also changes its resistance, but you will not be able to notice the difference here.

You can replace the white LED with the red LED (D1) or the color LED (D8), but they will not be very bright.



Slow On, Slower Off


Turn on the slide switch (S1), nothing happens. Now push the press switch (S2) and hold it down. The color LED (D8) takes a few seconds to turn on, then will very slowly get dim after S2 is released. The adjustable resistor (RV) controls the shut-off time.

You can replace the color LED with the red LED (D1) or the white LED

The 100uF capacitor (C4) controls the color LED through the PNP transistor (Q1). Pressing S2 quickly charges up the capacitor, and releasing S2 allows the capacitor to slowly discharge. Capacitors can store electric charge and release it when needed, so they are often used in timing circuits like this.



Project 169 Delayed Photo Speed Control



Turn on the switch (S1), the motor (M1) spins. As you move your hand over the phototransistor (Q4), the motor slows. Cover the phototransistor with your hand. The motor slows down and may stop, but will speed up in a few seconds. Also try shining a flashlight into the phototransistor.



Project 170 Delayed Speed Control

Use the preceding circuit, but replace the 100μ F capacitor (C4) with the much smaller 0.1μ F capacitor (C2). Now varying the light to the phototransistor has only a small effect on the motor speed.

Project 171Delayed Speed Control (II)


Use the circuit from project 169, but swap the locations of the phototransistor (Q4) and $5.1k\Omega$ resistor (R3); put "+" on Q4 towards C4. Now increasing the light to the phototransistor slows down the motor, instead of speeding it up.

Project 172Audio Delayed Speed Control

Use the circuit from project 169, but replace the phototransistor (Q4) with the microphone (X1, "+" on top). Clap, talk loudly, or blow into the microphone to change the motor speed.


Project 173 Photo Speed Control

Turn on the switch (S1), and set the adjustable resistor (RV) so the motor (M1) just spins. Slowly cover the phototransistor (Q4) and the motor spins faster. Place more light on the phototransistor and the motor slows down.



WARNING: Moving parts. Do not touch the fan or motor during operation.





Turn on the switch (S1). If there is enough light on the phototransistor (Q4), then nothing will happen. Cover the phototransistor with your finger, now the speaker (SP) makes noise and the color LED (D8) flashes. Wave your fingers over the phototransistor to vary the sound.


Replace the color LED with the red or white LEDs (D1 & D6). The light and sound will be a little different.

Delay Lights


Turn on the slide switch (S1), and push the press switch (S2). The color and white LEDs (D6 & D8) come on slowly but will stay bright for a long time after you release the press switch. Connect the red jumper wire across points A & B if you get tired of waiting for the LEDs to turn off.

Replace the 5.1k Ω resistor with the 100k Ω resistor. Now you have to push the press switch for much longer to make the LEDs bright.

Replace the 100μ F capacitor (C4) with the smaller 0.1μ F capacitor (C2). Now the LEDs turn on and off much faster, because C2 does not store as much electricity as C4.




Project 176 Touch Light



Build the circuit. It doesn't do anything, and may appear to be missing something. It is missing something, and that something is you.

Touch points A & B with your fingers. The white LED (D6) may be lit. If isn't bright, then you are not making a good enough electrical connection with the metal. Try pressing harder on the snaps, or wet your fingers with water or saliva. The LED should be bright now. You can replace the white LED with the red or color LEDs (D1 & D8).

Project 177 Narrow Range Tone




Turn on the switch (S1) and move the lever on the adjustable resistor (RV) around. The circuit makes a tone sound, but only over a small range of settings on RV.

Replace the $100k\Omega$ resistor (R5) with the $5.1k\Omega$ resistor (R3). The tone is a little different now.

Project 178





Turn on the slide switch (S1), and push the press switch (S2). The red and color LEDs (D1 & D8) stay on for a few seconds after you release the press switch.

You can change how long the LEDs stay on for by replacing the 100 μ F capacitor with the 0.1 μ F capacitor, by replacing the 100k Ω resistor (R5) with the 5.1k Ω resistor (R3), or by removing the 100k Ω resistor.

For more fun, try swapping the locations of the LEDs, or replacing either with the white LED (D6).

Look at the pictures here; they probably look blurry. Now place the red filter in front of your left eye and the blue filter in front of your right eye, and look at the pictures again. Now the pictures look clearer, and you can see them in three dimensions (3D).

3D Pictures



These pictures contain separate red & blue images, taken from slightly different viewpoints, combined together. When you view them through the red & blue filters, each eye sees only one image. Your brain combines the two images into the single picture that you "see", but the differences between the two images make the combined picture seem threedimensional.

How 3D works:


Most people have two eyes, spaced about 2 inches apart. So each eye sees the world a little differently, and your brain uses the difference in views to calculate distance. For each object in view, the greater the difference between the two scenes, the closer it must be. If you close one eye, you will have a harder time judging distance – try catching a ball with just one eye! (Be sure to use a soft ball if you try playing catch with one eye.)

When you watch a 3D movie in a theater, you wear 3D glasses so that each eye will see a different image. The movie screen actually shows two images, and the glasses filter them so that only one image enters each eye. Most movie theaters use polarized images and glasses with polarized lenses, so that each eye sees a different image.

Another way to make 3D is using red & blue images, then view using glasses with red & blue filters, as you are doing in this project. Unfortunately this method does not give you the color quality that the polarization method has.




3D Pictures





Project 180



Super Infrared Detector

Infrared light can be given off by anything warm. Sunlight and room lights emit some infrared light, in addition to visible light. This circuit is very sensitive, and may often be activated without a remote control. TV remote control receivers look for a sequence of pulses that identify an infrared message directed to their TV set model, so will not be activated by sunlight or room lights.



You need an infrared remote control for this project, such as any TV/stereo/DVD remote control in your home.

Build the circuit. The red LED (D1) will be dim. Turn on the switch (S1). Point your remote control toward the infrared module (U24) and press any button to activate the white LED (D6). Once activated, the white LED stays on until the switch is turned off.

Note: This circuit can activate without a remote control, due to infrared in sunlight or some room lights. If this happens, try moving to a dark room.

Test Equipment Depot - 800.517.8431 - 99 Washington Street Melrose, MA 02176 TestEquipmentDepot.com